



INSTALLATION INSTRUCTIONS

For use with:

HB-24EBX1:
Premise LED
HBX1-1

WHAT'S INCLUDED:

- Emergency battery driver enclosure with driver pre-attached
- Yoke mount
- Mounting screws

WHAT YOU'LL NEED (NOT INCLUDED):

- Wire cutters
- Wiring supplies as specified by electrical code
- Wire nuts/wago connectors
- Screwdriver
- Wrench
- Allen key set

IMPORTANT

In order to prevent an electric shock, do not connect the emergency power supply battery connection terminal and AC power before installing. Before disassembling or servicing, disconnect the AC power and unplug the emergency power battery connection terminal. Emergency power supply and AC driver must be on the same circuit branch. Do not install near flammable gases or heat sources. Before installing the emergency battery driver, please make sure that you carefully read through this instruction sheet. Consider having this sensor installed by a qualified licensed electrician.

Premise LED Inc.
80-86 Carrier Drive
Toronto, ON Canada
M9W 5R1
PREMISELED.COM

HB-24EBX1

INSTALLATION INSTRUCTIONS

TO INSTALL THE EMERGENCY BATTERY DRIVER:

1. Have emergency battery backup ready.
2. Remove the driver box screws and the ½" knockouts.
3. Feed the two cables from the emergency battery backup through the knockouts, securing them with the cable glands.
4. Connect the wires according to the wiring diagram below:
5. Attach the yoke mount to the battery driver enclosure with the supplied screws. Then attach the yoke mount to the light fixture body with the supplied screws. Then reattach the HBX1 driver box to the light fixture.

