



# MOTION SENSOR SETTINGS GUIDE



M6-7 Motion Sensor

Premise LED Inc.  
82-86 Carrier Drive  
Toronto, ON Canada  
M9W 5R1  
PREMISELED.COM

For use with:

### FL4 “-1” Series (120-277V)

FL4 “-1” (80-310W) | M6

FL4 “-1” (450W) | M7

### Factory Default Settings:

100% detection range, 5 second hold time, 5 second stand-by period, daylight sensor disabled, 10% stand-by dimming level

## BEFORE YOU BEGIN

Before beginning the setup of your motion sensor, please familiarize yourself with the sensor’s layout and dip switches.

\*DAYLIGHT SENSOR NOT IN USE DUE TO COVER\*.  
MUST ALWAYS BE SET TO “DISABLE”

### Detection Range

ON ↑ [DIP SWITCH]		1	2	
	I	ON	ON	100%
	II	ON	-	75%
	III	-	ON	50%
	IV	-	-	10%

### Hold Time

ON ↑ [DIP SWITCH]		3	4	5	
	I	ON	ON	ON	5S
	II	-	ON	ON	30S
	III	ON	-	ON	90S
	IV	-	-	ON	3min
	V	ON	ON	-	20min
	VI	-	-	-	+∞

### Stand-by Period

ON ↑ [DIP SWITCH]		6	7	8	
	I	ON	ON	ON	0S
	II	-	ON	ON	5S
	III	ON	-	ON	5min
	IV	-	-	ON	10min
	V	ON	ON	-	30min
	VI	-	ON	-	1h
	VII	-	-	-	+∞

### Daylight Sensor

ON ↑ [DIP SWITCH]		1	2	3	4	
	I	-	-	ON	ON	2Lux
	II	-	-	-	ON	5Lux
	III	-	ON	ON	-	10Lux
	IV	-	-	ON	-	25Lux
	V	-	ON	-	-	50Lux
	VI	ON	-	-	-	100Lux
	VII	-	-	-	-	Disable

### Stand-by Dimming Level

ON ↑ [DIP SWITCH]		5	6	
	I	ON	ON	50%
	II	-	ON	30%
	III	ON	-	20%
	IV	-	-	10%