

## DWRX/XXW/830/120DT DWRX/XXW/9CCT5/120DT

# LED Downlight Wafer Remote Driver

INSTALLATION INSTRUCTIONS

### **SAFETY PRECAUTIONS:**

- READ ALL INSTRUCTIONS BEFORE INSTALLING FIXTURE, RETAIN FOR FUTURE REFERENCE.
- IMPORTANT: This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- WARNING: For your safety, this fixture must be wired in accordance to local electrical codes and ordinances.
- WARNING: All work should be done by a qualified electrician.
- WARNING: Make certain power is OFF from the electrical panel before starting installation or attempting any maintenance.
- INDOOR INSTALLATION ONLY.

#### **INSTALLATION:**

#### ALWAYS TURN OFF THE POWER SUPPLY FROM MAIN CIRCUIT BREAKER FIRST!

- 1. Open the hardwire box swing cover and remove the appropriate knockout(s).
- 2. Insert the electrical supply cable through knockout and secure with a cable connector (sold separately).
- 3. Using connection terminal, connect green ground wire of cable to green wire on box.
- 4. Connect white wire of cable to white wire of box.
- 5. Connect black wire of cable to black wire of box. (Figure 1)
- 6. Place all wiring and connections back into the box and close the cover.
- 7. Insert hardwire box through the mounting hole. (Figure 2)

**New Construction Applications:** Hardwire box shall be firmly secured to studs, joists, or similar fixed structural units.

**Remodel Applications:** Hardwire box shall be firmly secured to studs, joists, or similar fixed structural units.

- 8. Make two holes in the wall, the spacing of the two holes is 1.6". Fix the hardwire box with screws. (Figure 3)
- 9. Connect the fixture to the hardwire box by inserting and twisting the male/female connectors. (Figure 4)
- 10. Push spring loaded clips on the fixture upwards and insert fixture base in to the mounting hole.
- 11. Release the clips and fixture will be pulled flush to the celling. (Figure 5)
- 12. Once assembly is complete, turn on power to confirm fixture is working properly.









